


POOL SAFETY


System state management

Your AQUALARM should always be in monitoring mode when there is no swimming in progress. **It is then up to you to manage the changes in status**, especially when you want to swim. The table below shows the different possible states, the light and sound signals associated with them, and the actions that can be taken from that state. Here is the instructions for the 2 modes of use:

ACTIVE ALARM

Related Signal	Flashing green light 
State	In monitoring mode (Swimming prohibited)
Possible actions	- Siren shutdown by pressing a button (Automatic shutdown after 60 seconds (configurable delay)): the monitoring is temporarily deactivated; it is automatically reactivated afterwards. - Entering the confidential code 1234 to enter swimming mode , the surveillance is deactivated; it is reactivated by manually switching to surveillance mode by 2 successive presses on OK (OK sequence, OK)
Related Signal	Siren triggered (Siren stop by pressing a button what-conch)
State	Alarm in progress

ALARM OFF

Related Signal	Flashing red light 
State	In swimming mode (Swimming allowed)
Possible actions	- Manual switch to monitoring mode by 2 successive presses on OK (OK OK sequence) It is recommended to wait for automatic reactivation for optimal sensitivity. If your pelvis is too agitated, the switch to manual mode will be refused and a serious beep will be emitted.
Related Signal	No Siren Triggered The system automatically reactivates after about ten minutes
State	Unsupervised (Bathing Mode)

When you want to swim, you should momentarily turn off your alarm and switch to swimming mode. To do this, type your PIN 1234. You have about ten minutes to enter the water. Beyond that, the system reactivates automatically.

Careful! The user shutting down the system should be aware that human monitoring needs to take over. The alarm is triggered when there is a fall or activity detected in the pool while the system is in monitoring mode. **It is imperative to react when the alarm sounds and to intervene as quickly as possible.**

After swimming, the system automatically reactivates when calm has returned to the pool. Nevertheless, you can speed up this process by reactivating the system yourself by pressing the OK key twice. The system informs you of the imminent reactivation of the monitoring (Reactivation in progress state) by the indicator lights that flash alternately, but above all by beeps at close range. Be careful, if calm has not completely returned to the pool, manual reactivation may be refused (serious beep). **The greatest vigilance of the responsible adult is necessary between the end of the swim and the reactivation of the alarm system.**



SAFETY NOTICE

Your pool is an extremely dangerous place for young children. Always remember that just a few seconds of inattention can have dramatic consequences. Since a child can drown silently in a few minutes in twenty centimetres of water, only active and constant supervision by adults can be effective. It is therefore important to never leave him alone and never take your eyes off him. **The installation of your AQUALARM system should in no way diminish your vigilance and your active and visual monitoring of the pool.** AQUALARM is a passive security feature that can help you if your children are thwarted by your surveillance, but you remain solely responsible for their safety.

Security Tip:

- Children should be closely and constantly supervised.
- Designate a single security officer.
- Reinforce supervision when there are multiple users in the pool.
- Wet your neck, arms and legs before entering the water.
- Do not dive or jump in the presence of young children
- Do not run and play around the pool.
- Do not allow access to the pool without a vest or bra for a child who does not know how to swim well and is not accompanied in the water.
- Do not leave toys nearby or in the pond that is unsupervised.
- This alarm is a safety device that signals a danger (or risk of danger). The rapid intervention in less than 3 minutes of a responsible adult is mandatory when the alert signal sounds.
- The user shutting down the system should be aware that human monitoring needs to take over.
- It is imperative to react when the failure signal sounds. • The utmost vigilance of the parent / responsible adult is necessary between the end of the swim and the reactivation of the alarm system.
- Performance as defined by the NF P 90-307-1 standard is not guaranteed beyond wind levels higher than those specified in this standard.
- During the automatic reactivation time, the responsible adult must supervise the pool by remaining at the edge for the time necessary for the system to resume its monitoring function. The effective reactivation is materialized by the passage of a red light
- Telephone accessible near the pool so that your children are not left unattended when you call.

IN THE EVENT OF AN INCIDENT:

- Get the child out of the water as quickly as possible
- Call for help immediately and follow the advice given to you
- Replace wet clothes with warm blankets.

EMERGENCY NUMBER:

